

e-OTONASHI Fanless Mini PC Case

- Assembly Guide -

[Caution!!]

- □ When installing EPIA Mini-ITX M-Series motherboard with a higher CPU into the chassis, a CPU fan needs to be removed.


 By using a different motherboard with a higher CPU, the warranty provided by VIA Technologies, Inc., will be voided. Hence, if you are installing a different motherboard with a higher CPU, please make sure to pre-test the system with a CPU fan attached in order to make sure the system will not overheat or damaged.
- □ Not recommend to use this chassis, where ambient temperature is high and/or there are heat generating devices around.

 Recommended to use under the environment where enough air flow is provided in order to achieve the best performance.
- □ Please refer to the Safety Precautions (separate sheet) in order to familiarize yourself with "heatlane" plate which is provided & manufactured by TS Heatronics Co., Ltd.

I. Before the Installation


1. Remove 3 screws located on the back of the chassis and take out the chassis cover. Then, remove the mounting plate for the HDD/slim drive bay by unscrewing 6 screws shown below.





II. Installation of the Heatlane Plate onto the Motherboard & the Chassis


- 1. As shown in Image2a, remove the heatsink from the motherboard, and also remove the CPU fan from the heatsink.
- 2. Carefully scrape thermal compound, and remove a thermal conduction sheet located between the heatsink and the CPU.
- 3. Evenly spread thermal compound onto the CPU as well as on the surface of the heatsink (between the heatsink & the heatlane plate).
- 4. Remove the heatlane plate from the chassis, and attach the heatlane plate onto the motherboard as shown in Image2b.
- 5. Tighten 4 nuts evenly (for securing the heatsink and the heatlane plate) to ensure proper pressure onto the CPU.
- 6. Install a motherboard rear-panel as shown in Image2c.
- 7. As shown in Image②b, and also refer to the user's manual of the motherboard, install the motherboard & the heatlane plate into the chassis.



III. Mounting Drives onto a Drivebay


- 1. Refer to Image③, install a HDD and/or a disk drive onto the drivebay.
- 2. Connect a cable as shown in Image(3)a.
- 3. Connect Power/Reset/Power LED/HDD LED cables as shown in Image(3)b, and also refer to the user's manual of the motherboard.

Image(3)



IV. Connecting cables to the Motherboard

- 1. Connect other cables by referring to Image(4), and also refer to the user's manual of the motherboard.
- 2. Secure a drivebay and a chassis cover by referring to Image①.



V. Before starting a computer

- 1. Connect all necessary devices (refer to the user's manual of the motherboard) to the motherboard.
- 2. Connect AC adapter into an adapter socket.
- 3. Connect a powercord into AC adapter, and plug it into an outlet.